

# PRE-CONSTRUCTION FOUNDATION ANCHOR

Load Bearing Wall

Basement or Crawl Space

Helical Driven to Load Bearing Strata.

Pre-Construction Bracket

Helical Driven to Load Bearing Strata.

Bands of rebar are attached to the top of each bracket, then encased in concrete.

Helical anchors installed prior to construction prevent downward settlement before it starts. By monitoring hydraulic pressures, anchors are load tested as they are installed.

Preserve the value of your new home or building. Use RAM JACK.

**RAM JACK**  
FOUNDATION REPAIR SYSTEMS  
4673315, #4911580, #45722298  
of West Virginia

Phone: (740) 374-2362  
Toll Free: (800) 616-6672  
[www.ramjackwv.com](http://www.ramjackwv.com)

WV Contractor Lic. #WV001906